




# Barnacle Buster Generator Flush with Port-O-Flush Jr.

Inlet point: connect the discharge hose of the Port-O-Flush JR.® to the FLUSHcap® at the top of the sea strainer cover, or connect the hoses with a barb fitting (see inset).

### Impeller

Remove the impeller, replace the faceplate and gasket.



Recovery point: connect the raw water discharge hose (from the exhaust elbow) to the recovery hose of the Port-O-Flush JR.® with a barb fitting (see inset).

Solution remains in system for 2 to 3 hours.



Port-O-Flush JR.® supply hose

Port-O-Flush JR.® recovery hose

Port-O-Flush JR.® flushing unit with premixed solution of Barnacle Buster® Concentrate and water.

### Barb Fitting

